

MORE FEET, FEWER STEPS.

Connects in less time, time after time.



First-time connection:



Step 1 – Cut WARDFLEX tubing and remove PE (polyethylene) coating to expose a minimum of four corrugations.



Step 2 – Slide nut over tubing and place retainer ring. Leave one corrugation exposed on the end of tubing.



Step 3 – Slide nut over retainer and hand-tighten nut to body.



Step 4 – Tighten with wrenches until nut contacts body.

Time-after-time re-usable re-connections without re-cutting.

WARDFLEX®

www.wardflex.com